

VIETA PRO

Kids Speaker

Ref. VM-BS14



English

LetMeRepair

Spain

Have a problem with your product?

Contact us at:

Email: vieta@letmerepair.es

Phone: 952 179 479

Dear customer,

Thank you for purchasing the

Kids VM-BS14 Bluetooth speaker.

To guarantee its correct operation,

it is recommended to read this manual carefully before starting to use the product.



MANUAL DE USUARIO



This product has been designed and developed under the professional standards of **VIETA PRO**, which was founded by the Brothers in 1954. Since then, Vieta has accumulated more than 60 years of history under the motto "The Avocation and Respect for Art of Music ", which has motivated all his projects, thus achieving a privileged and a privileged place in the electronics market based on constant effort and generous doses of passion.

The **VIETA PRO** models are based on the benefits of professional sound, where the standards of quality, durability, and sonority are above the commercial products of consumer electronics. Developed by the prestigious engineer "Jordi Hernández", with more than 40 years of experience in the electronics field and who has been designated as "expert hearing of vieta" since 2002. These models have been built with the most precise components for the purpose of being able to offer and develop the purity and uniqueness that characterizes the Vieta Pro sound.

Aux In mode



- Plug in the 3.5mm audio cable to enter AUX IN mode, or short press **(M)** to switch to AUX IN mode.
- Short press "▶||" for play/pause.
- Long press +/- for NEXT/PREV.
- Short press + for V+, short press - for V-.

FM mode




- Short press **(M)** to exchange to FM mode.
- Long press **(M)** to scan stations automatically with blue light blinking
- Long press +/- for NEXT/PREV
- Short press + for V+, short press - for V-.
- Insert AUX cable or charging cable as an external antenna to enhance FM signal



Charge


- Red light for charging, green light after fully charged.
- When there is no connection for 10secs, speaker will automatically shut down after 10min
- When battery power below 10%, there is low battery indication, please charge in time.



Button function

-  Long press: ON/OFF
-  Short press: exchange modes
-  Short press: pick/hang up a call
Long press: reject a call
Double click: dial a call

-  Short press: play/pause, mute
Long press: disconnect bluetooth
-  Short press: volume -
Long press: PREV
(TWS connection, press +/- together)

-  Short press: volume +
Long press: NEXT
(TWS connection, press +/- together)

Specification

Model: **Vieta Pro Kids**

Bluetooth Version 5.0

Dimensions: 98 * 76 * 38 mm

Weight: 225 gr

Driver: 45 mm/5W*1



Battery 3.7V/600mAh

Playing time: 5 hours at medium volume


Charging time: 2 horas

Transmission distance: <= 10m

Bluetooth Mode

- Bluetooth version: 5.0, supports HSP, HFP, A2DP, AVRCP profile. Pairing name is SDH-15C.
- ON/OFF: Long press  to turn on/off the speaker.
- Bluetooth pairing: when blue light blinking, speaker is ready for pairing, search **Vieta Pro Kids** in your phone for pairing, blue light stays after successfully paired.
- Long press  to disconnect bluetooth.

TWS mode

- Turn on two speakers and remain the bluetooth unconnected, long press +/- together of either speaker for TWS searching with blue light blinking. After TWS successfully connected, master speaker(left channel) blue light blinking and slave(right channel) flashes slowly. Then you can connect bluetooth to play music.
- Long press +/- together of either speaker for TWS disconnection, and master's bluetooth still connected.
- Long press  for bluetooth disconnection, and TWS still connected.

**VIETA
PRO**

www.vietapro.com